


JUNO AM-1625H

Size 950x950x2280mm



Key



P = Power supply

H = Hot water feed

C = Cold water feed

D1 = Drainage

All measurements are in mm.



Installation Requirements

Assembly

The shower is sectional and will be delivered in several boxes; all components will fit through standard doorways for assembly on site. This unit is built in position on a composite stone tray. You will require access around all exposed sides and above in order to assemble it.

Water Supply

The shower requires a supply of hot and cold water at a minimum of 1.5 bar of pressure. This can be achieved from a combination boiler/pressurised system or a pumped gravity/vented supply. Two braided flexible hot and cold supply pipes are provided with the shower and if connected where shown on the plan above will allow enough slack to move the shower in and out of position. It's also possible to extend the pipes and connect elsewhere.

Drainage

The tray is raised and has adjustable feet in order to level it. There is room underneath to accommodate the waste trap and flexible pipe.

Ventilation

No additional ventilation is required beyond what is necessary for a conventional shower as required by building regulations. The roof contains the water vapour within the cabin and the steam can be condensed to waste just by turning on the shower after use.

Electrical Connection

A 3.2kw supply is required which should be connected through an appropriate RCD (residual current device) protected fused spur or consumer board. We also recommend that an isolation switch is installed to cut the power to the transformer that powers the low voltage ancillaries (radio lights etc.). It is essential that all electrical work is carried out by a fully qualified electrician or inspected before use.